

CHARTIERS POST

ANCHOR INSTALLATION INSTRUCTIONS

1. Obtain proper anchor bolts, nuts, washers and template from manufacturer.
2. Pour a 36" concrete footer, making sure to adjust depth to your local frost level and leave access for the inlet supply line. (footer should be a minimum of 3" larger in diameter than the provided template)
3. Place ½ of each anchor bolts with threaded side up into the concrete.
4. Place the template over the anchor bolts with each anchor bolt aligning through the 4 holes of the template.
5. Press the anchor bolts down into the concrete leaving approximately 2" of the threaded bolt above the concrete surface.
6. After situating to desired position, let concrete dry thoroughly. (Do not attempt the next step until the concrete has thoroughly hardened)
7. Remove the four nut covers from the base.
8. Place the base over the anchor bolts and secure using one washer and one nut per bolt.
9. Apply the nut covers.
10. Sit the cap on top of the base.
11. Place the aluminum post down through the cap and the base.
12. Carefully slide the cap up and tighten the (3) screws in the top of the base to secure the aluminum post in place.
13. Slide the cap back down and secure it to the base by tightening the (3) screws.
14. For Gas: With the coiled end at the top, slide the gas feed line down through the top of the post. Remove the access plate from the bottom of the base(remove the (2) screws on each side of the plate) to access the connections then replace it when all connections are made.
15. For Electric: Feed the main line in through the inlet supply access and up through to the top of the post.
16. Follow the installation instructions packed with the lamp.

